
# Fotómetro IoT




**Rev 2.0** 


## Fotómetro IoT

• Basado en el IC TSL2561


#### **Functional Block Diagram**





### Fotómetro Conectividad



# Fotómetro I/O







#### Photometer operating modes


- -Cloud mode: when WIFI is available (yellow jumper open at power on)
- -Standalone mode: when WIFI is not available (yellow jumper closed at power on)
- -In both cases serial output is available. Output Rate: 1 sample every 2 seconds<sup>(1)</sup>
- -Cloud mode: Samples are sent to cloud and from cloud to phone apk (illuminance.apk)
- -WIFI parameters setup

Wireles router / AP / Hotspot Name : IOT WIFI

Password: GEDA2016


#### **Tests**

### Automated Gamma Measurement for LCD display using Matlab Setup




Fotometer






#### **Tests**

Automated Gamma Measurement for LCD display using Matlab: Measurement Loop



#### Tests: Samsung T24C550

Automated Gamma Measurement for LCD display using Matlab Results:



### Tests: Samsung T24C550


Automated Gamma Measurement for LCD display using Matlab Results:

Gamma Control	Measured Gamma
-3	1.6
0	1.8
+3	2.1

#### Matlab Files


**Luxmeter.m**: Returns Light Luminosity in lux

**Luxtest.m**: Photometer Measurement Program



#### Measurement setup and use

- 1- Connect the photometer to USB to serial converter
- 2- Connect the photometer to power supply
- 3- Connect the USB serial converter cable to computer USB port
- 4 Find out the USB serial port on computer (COMxx)



5- Edit and modify serial port on luxmeter.m

#### Measurement setup and use


- 6- Attach photometer as close a possible to monitor
- 7- Open matlab and run luxtest.m

Notes: Each sample is taken every 2 seconds (defined on firmware)

Two samples are taken per gray level and averaged

(see Nmeas on luxtest.m)

#### Schematic



### APP: Illuminance.apk



http://personal.ik.itba.edu.ar/~jacoby/ilum/